



If the track is not going to be centered in the doorway, use this formula to determine the distance from the edge of the door to the edge of the track . You should add one inch to the 'D' dimension for clearance between the door opening and the carriage.