





## Full length Pontoon Bunks

First, determine the center to center distance of your pontoons and set the bunks to match this dimension. The end of the bunks that has more wood over-hanging, goes to the rear of the carriage. Place a 1/2" x 3" shim under the side of the bunk that is over the extension (or outside) portion of the carriage. Make sure that the shim is flush with the edge of the bunk bracket, and that the u-bolt pinches the shim securely. Use 2 u-bolts per bracket, as shown. The angle braces with the wood on them are to protect the pontoons from damage by the angle bracket.

